

## C&DH


CAUTION  
ALARM


Attention Symbol  
will appear on card

User Notification  
Attention Symbol, or  
call from crew, or  
another console  
with funny data

**Nominal Config:**  
Comm Via Early  
Comm or OIU

## NODE 1 MDM I/O CARD FAILURE PROCEDURE





③

Check with **MCC** to decide if want to power cycle the MDM to try and regain the I/O card.